

1507/1503 Series Reference Card


Front

FLUKE®


1507/1503 Insulation Tester Quick Reference Guide

⚠ See *Users Manual* for "Safety Information" and complete operating information.

Fuse Test 




Battery and Fuse Replacement 



1507/1503 Quick Reference Card

Back

Measuring Insulation Resistance



Compare Function (1507)

