




Operation remains smooth and fluid in manual operation (power outage, etc.)

The electronic drive simply replaces the manual effort you would otherwise make

Easy to retrofit




WE THINK OF EVERYTHING

INTEGRATED LIGHT CONTROL

 KESSEBÖHMER



Connection point for 24 V lighting system.



Plug in cable for the lighting system and it will switch on/off automatically when the cabinet is opened/shut.

	Item no.
Set eTouch drive unit	271962 7035
FREEfold/FREEswing/FREEslide Grey	
1x drive unit (with 2 premounted screws (wood) 4x 10 mm)	
1x M4x 8 mm	
1x wood screw 4x 35mm	
1x power cable	
2x radio sensor	
1x drilling template KS for sensors	
1x strain relief clip	
1x ferrite	



Set eTouch swing arm	Lever length type::	
FREEslide (replacement lever arm LEFT)	O	271964 0006
nickel-plated	P	271965 0006
	Q	271966 0006
	R	271967 0006



Set eTouch swing arm	271968 0006
FREEswing (replacement lever arm LEFT)	
nickel-plated	



Power cable eTouch	Country variants::	
FREEfold/FREEswing/FREEslide/FREEflap	EU	271973 9005
Black	US/JPN	271974 9005
	AUS	271975 9005
	UK	271976 9005



Connecting rod anodised aluminium

Carcase width mm	Carcase wall mm	Length mm	Item no.	Carcase width mm	Carcase wall mm	Length mm	Item no.
450	16/19	299	271977 0038	900	16/19	749	271981 0038
500	16/19	349	271978 0038	1.000	16/19	849	271982 0038
600	16/19	449	271979 0038	1.200	16/19	1.049	271983 0038
800	16/19	649	271980 0038	KB	16/19	KB-(2 x K)-88 -25	



Set of eTouch dress covers		
FREEfold	FREEfold	FREEfold short
Grey	271969 7035	272041 7035
Ice white	271969 9966	272041 9966
Anthracite	271969 7500	272041 7500



Set of eTouch dress covers	
FREEswing	
Grey	271971 7035
Ice white	271971 9966
Anthracite	271971 7500



Set of eTouch dress covers	
FREEslide	
Grey	271970 7035
Ice white	271970 9966
Anthracite	271970 7500

