FLUKE

175/177/179 True-rms Multimeters Safety Information



Lifetime Limited Warranty. See the Users Manual for the full warranty. gloves, face protection, and flame-resistant clothes) to prevent shock and arc blast injury where hazardous live conductors are exposed.

- Limit operation to the specified measurement category, voltage, or amperage ratings.
- Use Product-approved measurement category (CAT), voltage, and amperage rated accessories (probes, test leads, and adapters) for all measurements.
- Only use probes, test leads, and accessories that have the same measurement category, voltage, and amperage ratings as the Product.
- · Use only cables with correct voltage ratings.
- Do not exceed the Measurement Category (CAT) rating of the lowest rated individual component of a Product, probe, or accessory.
- Do not use in CAT III or CAT IV environments without the protective cap installed on test probe. The protective cap decreases the exposed probe metal to <4 mm. This decreases the possibility of arc flash from short circuits.
- Do not touch voltages >30 V ac rms, 42 V ac peak, or 60 V dc.
- · Keep fingers behind the finger guards on the probes.
- Use only current probes, test leads, and adapters supplied with the Product.
- Connect the common test lead before the live test lead and remove the live test lead before the common test lead.
- Do not apply more than the rated voltage, between the terminals or between each terminal and earth ground.
- Measure a known voltage first to make sure that the Product operates correctly.
- Use the correct terminals, function, and range for measurements.
- Do not touch the probes to a voltage source when the test leads are connected to the current terminals.
- Remove the batteries if the Product is not used for an extended period of time, or if stored in temperatures above 50 °C. If the batteries are not removed, battery leakage can damage the Product.
- The battery door must be closed and locked before you operate the Product.
- Remove all probes, test leads, and accessories before the battery door is opened.
- Replace the batteries when the low battery indicator shows to prevent incorrect measurements.

Symbols

Symbol	Description
Ĩ	Consult user documentation.
⚠	WARNING. RISK OF DANGER.
	WARNING. HAZARDOUS VOLTAGE. Risk of electric shock.
OFF	Turns off the Product.
Ŧ	Earth
~	AC (Alternating Current)
	DC (Direct Current)
~	Both direct and alternating current.
-+-	Capacitance
	Fuse
	Double Insulated
IR	Minimum fuse interrupt rating.
u)))	Continuity test or continuity beeper tone.
Ê	Low battery. Replace battery.
CE	Conforms to European Union directives.
	Certified by CSA Group to North American safety standards.
Ò	Conforms to relevant Australian Safety and EMC standards.
No.	Conforms to relevant South Korean EMC Standards.
САТ ІІ	Measurement Category II is applicable to test and measuring circuits connected directly to utilization points (socket outlets and similar points) of the low-voltage MAINS installation.
САТШ	Measurement Category III is applicable to test and measuring circuits connected to the distribution part of the building's low-voltage MAINS installation.
САТ 🛙	Measurement Category IV is applicable to test and measuring circuits connected at the source of the building's low-voltage MAINS installation.
X	This product complies with the WEEE Directive marking requirements. The affixed label indicates that you must not discard this electrical/electronic product in domestic household waste. Product Category: With reference to the equipment types in the WEEE Directive Annex I, this product is classed as category 9 "Monitoring and Control Instrumentation" product. Do not dispose of this product as unsorted municipal waste.

Specifications

opeenieulene			
Accuracy is specified for 1 year after calibration, at operating temperatures of 18 °C to 28 °C, with relative humidity at 0 % to 90 %. Accuracy specifications take the form of: ([% of Reading] + [Counts])			
Maximum voltage between any terminal and earth ground1000 V			
▲ Fuse Protection for mA inputs0	0.44 A, 1000 V, IR 10 kA		
▲ Fuse Protection for			
A inputs 1			
	Digital: 6000 counts, updates 4/sec		
Bar Graph	33 segments, Updates 40x/sec		
Frequency1	10 000 counts		
Capacitance1	1000 counts		
Altitude			
Operating2	2000 m		
Storage1	12 000 m		
Temperature			
Operating	-10 °C to +50 °C		
Storage	–40 °C to +60 °C		
	0.1 X (specified accuracy) / °C, (<18 °C or ⊳28 °C)		
	Maximum non-condensing) 90 % to 35 °C, 75 % to 40 °C, 45 % to 50 °C		
Battery Life	Alkaline: 400 hrs typical		
Size (H x W x L)4	4.3 cm x 9 cm x 18.5 cm		
Weight	420 g		
Safety			
GeneralI	EC 61010-1: Pollution Degree 2		
	EC 61010-2-033: CAT IV 600 V / CAT III 1000 V		
Electromagnetic Compatibility (EMC)			
E	EC 61326-1: Portable Electromagnetic Environment CISPR 11: Group 1, Class A, EC 61326-2-2		

Group 1: Equipment has intentionally generated and/or uses conductivelycoupled radio frequency energy that is necessary for the internal function of the equipment itself.

Class A: Equipment is suitable for use in all establishments other than domestic and those directly connected to a low-voltage power supply network that supplies buildings used for domestic purposes. There may be potential difficulties in ensuring electromagnetic compatibility in other environments due to conducted and radiated disturbances.

Emissions that exceed the levels required by CISPR 11 can occur when the equipment is connected to a test object. The equipment may not meet the immunity requirements of this standard when test leads and/or test probes are connected.

Korea (KCC).....Class A Equipment (Industrial Broadcasting & Communication Equipment)

Class A: Equipment meets requirements for industrial electromagnetic wave equipment and the seller or user should take notice of it. This equipment is intended for use in business environments and not to be used in homes.