

TECHNICAL DATA

Fluke 1630-2 FC Earth Ground Clamp



Stakeless earth ground loop and ac leakage current clamp for fast, safe indoor/outdoor earth ground resistance and ac leakage current tests.

Test the grounding components of equipment in hard-to-reach spaces, including areas that are indoors or fully paved and do not permit driving auxiliary test stakes. Stay on line—identify ground loop resistance without the need to disconnect then reconnect the earth electrode from the system.

The Fluke 1630-2 FC Stakeless Earth Ground Clamp is the kind of high-quality, rugged tool you expect from Fluke. Heavy-duty clamp jaw stays in alignment and in calibration even in every day, on-the-job industrial environments.

Stakeless measurement

The 1630-2 FC clamp measures earth ground loop resistances for multi-grounded systems using the dual-clamp jaw. This test technique eliminates the dangerous and time-consuming activity of disconnecting parallel grounds, as well as the process of finding suitable locations for auxiliary test stakes. You can also perform ground tests in places that were previously difficult: inside buildings, on power pylons or anywhere you don't have access to soil to place auxiliary test stakes.

With this test method, a two-process measurement is made around the earth ground wire or bus bar using the specially-designed jaw of the 1630-2 FC clamp. Auxiliary test stakes are not used at all. A known voltage is induced by the source in the clamp, and the current is measured by the sensor in the clamp. The tester automatically determines the earth loop resistance for this section of the earthing system.

AC LEAKAGE CURRENT MEASUREMENT

Identify ac leakage currents without disconnecting the earth ground stake from the grounding system—ideal for system troubleshooting.

RUGGED

Heavy-duty clamp jaw stays in alignment and in calibration even in every day, on-the-job industrial environments.

LOGGING MEASUREMENTS

The earth ground clamp saves time by automatically recording data at pre-set intervals and saves up to 32,760 measurements in memory at the set logging interval. Saves time by recording and storing measured values.

ALARM THRESHOLD

User-defined high/low alarm limits, for rapid measurement evaluation.

BAND-PASS FILTER

Selectable band-pass filter function removes unwanted noise from the ac leakage current measurement.



FLUKE CONNECT® WIRELESS SYSTEM

The 1630-2 FC supports the Fluke Connect® Wireless System (may not be available in all regions). Fluke Connect® wirelessly connects the clamp with an app on your smartphone or tablet. The app shows the ground resistance measurements on your smartphone or tablet display. You can save *Authorized Distributor* GPS location from your phone and images storage and share with your team.

Specifications

Electrical specifications

| | | | |
|---|--|--|---------|
| Maximum voltage to earth ground | 1000 V | | |
| Battery type | 4 x 1.5 V AA alkaline IEC/EN LR6 | | |
| Battery life | More than 15 hours* | | |
| Frequency range | 40 Hz to 1 kHz | | |
| Ingress protection | IEC/EN 60529: IP30 with jaw closed | | |
| LCD | Digital reading | 9999 counts | |
| | Refresh rate | 4/s | |
| Temperature | Operating | -10 °C to +50 °C (14 °F to +122 °F) | |
| | Storage | -20 °C to +60 °C (-4 °F to +140 °F) | |
| Operating humidity | Non condensing (<10 °C) (< 50 °F) | | |
| | ≤90 % RH (at 10 °C to 30 °C [50 °F to 86 °F]) | | |
| | ≤75 % RH (at 30 °C to 40 °C [86 °F to 104 °F]) | | |
| | ≤45 % RH (at 40 °C to 50 °C [104 °F to 122 °F]) (Non condensing) | | |
| Altitude | Operating | 2000 m (6561 ft.) | |
| | Storage | 12,000 m (39370 ft.) | |
| Reference temperature | 23 °C ±5 °C (73 °F ±9 °F) | | |
| Temperature coefficient | 0.15 % X (specified accuracy)/ °C (<18 °C or >28 °C [<64.4 °F or >82.4 °F]) | | |
| Overload indication | OL | | |
| Display Reading Specification with Loop Resistance Standard | Input (Ω) | Minimum | Maximum |
| | 0.474 | 0.417 | 0.531 |
| | 0.5 | 0.443 | 0.558 |
| | 10 | 9.55 | 10.45 |
| | 100 | 96 | 104.0 |
| Data logging capacity | Minimum of 32,760 measurements | | |
| Data logging interval | 1 second to 59 minutes and 59 seconds | | |
| Safety | General | IEC/EN 61010-1: Pollution Degree 2 IEC/EN 61557-1 | |
| | Measurement | IEC/EN 61010-2-032: CAT IV 600 V / CAT III 1000 V | |
| Current clamp for leakage current measurements | IEC/EN 61557-13: Class 2, ≤30 A/m | | |
| Resistance to Earth | IEC/EN 61557-5 | | |
| Effectiveness of the protective measures | IEC/EN 61557-16: cutoff frequency 20 kHz (-3 dB) | | |
| Electromagnetic compatibility (EMC) | International | IEC/EN 61326-1: Portable Electromagnetic Environment CISPR 11: Group 1, Class B, IEC/EN 61326-2-2 | |
| | Korea (KCC) | Class A equipment (Industrial Broadcast & Communications Equipment) | |
| | USA (FCC) | 47 CFR 15 subpart B. This product is considered an exempt device per clause 15.103. | |

* In Ground Resistance measurement mode, with backlight turned off, and RF mode turned off

Wireless radio

| | |
|-------------------------------|-------------------------------|
| Frequency range | 2412 MHz to 2462 MHz |
| Output power | <10 mW |
| Radio frequency certification | FCC ID:T68-FBLE IC:6627A-FBLE |

General specifications

| | | |
|------------------------|---|---|
| Conductor size | 40 mm (1.57 in) approximately | Authorized Distributor www.aabtools.com |
| Dimensions (L x W x H) | 283 mm x 105 mm x 48 mm (11.1 in x 4.1 in x 1.9 in) | |

FLUKE®

Earth ground loop resistance

| Range | Accuracy [1] (± % of reading + Ω) |
|--------------------|--------------------------------------|
| 0.025 Ω to 0.249 Ω | 1.5% + 0.02 Ω |
| 0.250 Ω to 0.999 Ω | 1.5% + 0.05 Ω |
| 1.000 Ω to 9.999 Ω | 1.5% + 0.10 Ω |
| 10.00 Ω to 49.99 Ω | 1.5% + 0.30 Ω |
| 50.00 Ω to 99.99 Ω | 1.5% + 0.50 Ω |
| 100.0 Ω to 199.9 Ω | 3.0% + 1.0 Ω |
| 200.0 Ω to 399.9 Ω | 5.0% + 5.0 Ω |
| 400 Ω to 599 Ω | 10.0% + 10 Ω |



Preventive maintenance simplified. Rework eliminated.

Save time and improve the reliability of your maintenance data by wirelessly syncing measurements using the Fluke® *Authorized Distributor*

- Eliminate data-entry errors by syncing data from your tool and associating them with the work order.

AABTools
INDUSTRIAL SUPPLIES

www.aabtools.com